






What's new **Kelio Access 5.1**






1


New identity guidelines

REVISED IDENTITY GUIDELINES


The Kelio identity guidelines have been re-designed. From the new customisable login page to the new rounded portal icons: a more modern look for your employees!



Home page



Rounded icons



Colour gradients


One business function = one colour!

Do you manage your company's HR? Or perhaps time and attendance management? Or perhaps both?


Kelio allows you to customise different screen colours depending on the module, all with a dynamic colour gradient!

Default colours are pre-selected:


Human Resources




Setup / Configuration



Time & Activities / Planning



Access control management





2

Hardware

KELIO XTREM TERMINAL – BLUETOOTH/NFC



Clock in instantly from your smartphone: this is now available on the Kelio Xtrem terminal!

Modern smartphones include the technological protocols NFC (Near Field Communication) or BLE (Bluetooth Low Energy) by default. These technologies enable smartphones to interact securely with our terminals and readers, just like a badge.

This means you can benefit from having a **digital badge**, and use your phone to clock in or out.

Forgotten your phone? No problem - you can always use your MIFARE DESFire physical badge.



BLUETOOTH/NFC



In order to meet all of your requirements, we now offer a full range of MIFARE Bluetooth/NFC hardware.



Visio X4*, X7*



Xtrem*



Kelio Pass RS

**Available in digital fingerprint version*



3

Kelio Access

NEW KELIO RANGE V5.1

As an existing client, you benefit from an update to the new **Kelio Access** module and all its features, free of charge.

	KELIO ACCESS
Event history	✓
Access rule management	✓
Real-time alerts – SMS / Emails	✓
Monitoring	✓
Real-time monitoring of access crossing	✓
Auto Events	✓
Visitors	*
Room bookings	*
Video surveillance link	*


✓

As standard

*


Optional module

REORGANISATION OF MODULES



REORGANISATION OF MODULES

All modules that were in Java have been replaced, making them available in full web version. This means you no longer need to install a plug-in locally on your workstation in order to use them.



NEW ACCESS CONTROL MODULE

You can now access the administrative and operational features of your access control system via a single module, in full web version.

The image displays two screenshots of the Kelio Access control web interface, demonstrating its administrative and operational capabilities.

Left Screenshot (Setup Tab): The interface shows the 'SETUP' tab selected. The top navigation bar includes 'Setup', 'Functional rules', 'Schedules', 'Exceptions', and 'Anti pass-back'. The left sidebar lists various modules: Access, Public holidays, People, Visits, Organisation chart, Customisable fields, Rooms, Alarms/Emergency, Auto Events, and Supervision. The main content area displays configuration options for 'Entrance employees', including 'Model', 'Location', 'Message on Visio touchscreen', 'Access opening', 'Deny access', 'Access crossing', 'Relay activation timeout', 'Default annual schedule', 'Use of following readers', 'Remote push button', 'Collective Access mode', 'Identification mode', 'Authentication Mode', 'Access code rule', 'Off-line mode rule', 'Green manual trigger rule', and 'Emergency door release trigger'.

Right Screenshot (Administrate Tab): The interface shows the 'ADMINISTRATE' tab selected. The top navigation bar includes 'Individual file', 'Staff planning', 'User rights', 'Access user', 'Personal data', 'Professional data', and 'Customisable fields'. The left sidebar lists various modules: Employees, Visitors, Access, Supervision, and Disallowed events. The main content area displays user management features, including 'Access user', 'Identity', 'Registration', 'Access methods', and 'Access profiles'. The 'Access user' section shows details for 'ABBY A. Arnaud', including 'Surname', 'First name', 'Abbreviation', 'Registration', 'Public holiday calendar', 'Access methods', and 'Access profiles'. The 'Access methods' section shows 'Badge 1 no' and 'Badge 2 no' with 'Last read' and 'Disallowed event' buttons. The 'Access profiles' section shows a table with columns: Site, Profile, Start date, and End date.

Bottom Screenshot (Filter the Architecture Tab): The interface shows the 'Filter the Architecture' tab selected. The top navigation bar includes 'Managed sites', 'Quantum Ltd', 'Main entrance', 'Factory', 'Office 1', 'IT department', 'Production Hall', and 'Stock'. The main content area displays a table with columns: Site, Description, and Model. The table lists various sites and their corresponding descriptions and models.




4

Configuration Module

NEW CONFIGURATION MODULE

As an administrator, there are 2 entry points available to you on the portal: **Configuration** and **Access control**.

The Configuration module can also be accessed via a tile.



NEW CONFIGURATION MODULE

Two new **Software** and **Hardware** menus offer improved differentiation between the 2 themes, for easier configuration.

The image displays two screenshots of the Kelio Configuration module interface, illustrating the new Software and Hardware menus.

Left Screenshot (Hardware Configuration):

- Header:** Kelio OFFICIAL DATE AND TIME 16:23 Thursday, 9 February 2023 Configuration Tools Display About Help Exit
- Navigation:** You are managing the population Population Admin et Prod Hardware SOFTWARE
- Left Sidebar:** Infrastructure Architecture Badges
- Main Content:** Hardware devices Power supplies. The diagram shows Ethernet devices (10.48.39.111, 192.168.147.50) connected to a USB device (OPN2001 reader(s) (1)) via an X7-gsm interface.
- Bottom Panel:** FILTER THE ARCHITECTURE Managed sites Kelio Démonstration


Right Screenshot (Software Configuration):

- Header:** Kelio OFFICIAL DATE AND TIME 04:27 PM Thursday, 9 February 2023 Configuration Tools Display About Help Exit
- Navigation:** You are managing the population Bodel Software/UK Hardware SOFTWARE
- Left Sidebar:** Enterprise Customisation Processing System administr...
- Main Content:** Sites. The form includes fields for Description (Quantum Ltd), Abbreviation (S0001), and contact information (Address, Postcode, Town, Country, Legal form, SIRET/SIREN).
- Bottom Panel:** Search on all the columns Description [4] Abbreviation. The table lists sites: Quantum CH (S0003), Quantum France (S0002), Quantum Ltd (S0001), and Site ES (S0004).

NEW CONFIGURATION MODULE

A new screen displays a view of your **Infrastructure**:

- Redesigned tree view, with graph view of access control hardware and Time & Attendance management where applicable
- Full and comprehensive Kelio architecture
- Easier hardware installation and maintenance
- Multi-site view




NEW CONFIGURATION MODULE

Based on your profile, various **filters** allow you to view:

- Access readers
- HR terminals
- Connected or disconnected hardware
- Disabled hardware devices.


The filter can also be customised, to better meet your needs (connection status, usage, badge-reading system).



NEW CONFIGURATION MODULE

The **search function** enables you to locate a piece of hardware more efficiently, based on its name or IP address.

It will be highlighted within a list of all hardware devices.



NEW CONFIGURATION MODULE

So that you can access more information on each hardware device, there is a screen where you can input all the relevant **information**, while a **photo** helps you to easily identify the type of hardware device.


The screenshot displays the Kelio Configuration interface. The top bar shows the time as 04:47 PM on Thursday, 9 February 2023, and the title 'Configuration'. The main menu on the left includes 'Infrastructure', 'Architecture', and 'Badges'. The central panel is titled 'Modify the hardware Kelio Pass' and contains the following fields and sections:

- Description:** New Pass reader
- Abbreviation:** R0011
- Master hardware:** Neue Lesemodul-Schnittstelle
- Connection:**
 - Connection mode: RS485 - Polling
 - Identifier: 1
- Use of the reader:**
 - ☐ In Time and Attendance management
 - ☐ In Job Costing management
 - ☐ In Signature management for people present during the fire alarm
 - ☒ In access management
 - ☒ Authorised for several access points/equipment
 - Access/managed equipments: [dropdown menu]
 - ☐ In alarm management
 - Reader groups: [dropdown menu]
- Internal reader:**
 - Model: MIFARE
 - Configuration: Proximité 26b
- Power supply:**
 - Consumption (mA): 0

At the bottom right of the form are 'Validate' and 'Cancel' buttons.

NEW CONFIGURATION MODULE

Areas and **access points** can be configured through this new module, enabling you to design a detailed and comprehensive architecture. You can illustrate each access point using the icons, making administration easier.



OUR SERVICES



Audit and project support

Kelio solutions training

Quality monitoring

Kelio and GDPR

Software in SaaS mode



Kelio

GLOBAL WORK-LIFE SOLUTIONS

CS 40211 | Boulevard du Cormier
49302 CHOLET Cedex | FRANCE
www.kelio.com

